

ASSEMBLY INSTRUCTIONS

Wall-Pass Thru Assembly DVD0079

Tools and Materials that may be required:

- Adjustable wrench ½ or socket set
- 3/8 Inch drill bit/electric drill [concrete drill bit may be necessary for floor anchoring]
- Other tools/materials may also be necessary depending upon actual installation
- Installation Hardware Kit included – locate white hardware kit box



dVault Company, Inc. • 9800 Mount Pyramid Court • Suite 400 • Englewood, Colorado • 80112
Phone: (720) 895-1908 • Fax: (720) 895-1909 • World Wide Web: <http://www.dvault.com>

dVault