

INSTALLATION INSTRUCTIONS

Sharps Express DVCS0023

Installation Procedure:

1. Confirm installation site with onsite management prior to installation
2. Site Prep – installation site must be free off dirt, moisture and wall debris.
3. Remove Sharps Express unit from packaging and open from access door.
4. Remove gray recycling container from unit and remove packaging.

Skip Steps 5, 6 & 7 if securing to wall or floor is not needed.

5. Position unit against the wall where unit is to be installed. Locate anchoring holes and center mark holes for drilling [wall mount – rear panel, floor mount – bottom panel, or both]

WARNING: DO NOT DRILL HOLES DIRECTLY ABOVE OR BELOW WALL OUTLETS

6. Remove the Sharps Express unit and set aside to gain access to drill marks and drill holes. Note: 4 lag screws are also provided for possible solid wall or wall stud anchoring configurations [see Figure 2]

Floor Anchoring – install 4 expansion anchors provided [see Figure 3]

Wall Anchoring – re-position Sharps Express near install site wall and insert 4 toggle bolts through hole and spacers provided [see Figure 1 & 2]

7. Align unit against wall anchoring holes. Insert toggle bolt wing nut through wall anchoring holes and thumb tighten until floor-anchoring holes are aligned with expansion anchors installed in step 6 – if used. If used, insert 4 floor anchor bolts and tighten all screws and bolts as needed.
8. Re-insert recycling container into Sharps Express and close front access door to locked position.
9. Clean unit and remove all packaging and hardware debris.

(Unit diagram on reverse side for hardware selection and configurations)

dVault Company, Inc. • 9800 Mount Pyramid Court • Suite 400 • Englewood, Colorado • 80112
Phone: (720) 895-1908 • Fax: (720) 895-1909 • World Wide Web: <http://www.dvault.com>

